



# Samsung SCH-8500 Teardown

Teardown of Samsung SCH-8500

Written By: William Maddrey



## INTRODUCTION

This is a teardown of the Samsung SCH-8500.

---



### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
  - [Metal Spudger](#) (1)
  - [T6 Torx Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-



## Step 1 — Samsung SCH-8500 Teardown



- The phone we are taking apart today is the Samsung SCH-8500

## Step 2



- Press on black button next to battery and use metal spudger or other pointy object to pop the battery of the back.

## Step 3



- Remove 4 0.6mm screws with a T6 Screwdriver.


## Step 4



- Remove the little rubber piece.
- Then gently lift off back case.



## Step 5



- Unscrew the antenna from back case.

## Step 6




- Pry off the 2 covers on the display.

## Step 7



- Remove the 2 0.3mm screws from display


## Step 8



- Pry the speaker cover off display, to reveal 2 screws.




## Step 9




- Remove 2 0.3mm screws.

## Step 10



- Use a case opening tool and pry the case of the display.

## Step 11



- Pry the display, speakers, and main board of of phone
- Take off the keys

## Step 12



- Voila! You're done.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-30 05:55:08 PM.